



Spare parts available at:
spares.bagnallandkirkwood.co.uk

For spare parts not listed please contact us using the reference codes above

NO	ART. NO	DESCRIPTION	NO	ART. NO	DESCRIPTION
1	2002	AIR CYLINDER [STANDARD]	31	5000	INLET VALVE
2	2004	BARREL HOUSING	32	2036	AIR TRANSFER PORT 4.1
3	2010	HAMMERHOUSING COVER	33	2038	HAMMER SPACER
4	2011	HAMMER HOUSING	34	2040	PLASTIC VALVE SEAL
5	2009	END PLUG	35	2039	BRASS SPACER 6,6
6	2012	MAIN VALVE HOUSING	36	2041	VALVE SEAL HOLDER
7	2013	VIBRATION DAMPER	37	2044	BARREL .22
8	2008	FRONT PLUG	38	2047	BARREL .177
9	2014	MAIN VALVE LID	39	2050	MAGAZINE .22
10	2015	BARREL HOLDER	40	2053	MAGAZINE .177
11	FP3	FILL PROBE	41	2056	BRASS BARREL INLET .22
12	2070	SIDEPLATE	42	2057	BRASS BARREL INLET .177
13	2016	COCKING BOLT [BLACK]	43	2058	PELLET PROD .22
14	2018	PRESSURE GAUGE SPACER	44	2059	PELLET PROD .177
15	2019	TRIGGER BLOCK	45	2042	PLASTIC WASHER
16	2020	TRIGGER BLADE	46	5003	PLASTIC WASHER
17	2021	TRIGGER BASE	47	2043	PRESSURE GAUGE
18	2022	MAIN VALVE PIN	48	2531	RUBBER BALL
19	2023	VALVE SEAT	49	2517	PIVOT PIN
20	2025	HAMMER FOOT	50	2518	PIVOT PIN
21	2026	HAMMER PIN	51	2524	SPRING
22	2027	INDEX LEVER	52	2525	SPRING
23	2028	INDEX LEVER CONNECTOR	53	2519	SPRING
24	2029	MAGAZINE STOP	54	2522	SPRING
25	2030	MUZZLE END CAP	55	2523	HAMMERSPRING [HARD]
26	2031	VALVESCREW	56	2520	SPRING
27	2032	COCKING BOLT SPACER	57	BK5	O-RING
28	2033	TRIGGER CAP	58	BK14	O-RING
29	2034	MAGAZINE PIN	59	BK38	O-RING .177 (4,5mm)
30	2035	MAGAZINE PIN HANDLE	60	BK48	O-RING

NO	ART. NO	DESCRIPTION
61	BK51	O-RING
62	BK89	O-RING
63	BK112	O-RING
64	2500	SCREW
65	2501	SCREW
66	2502	SCREW
67	2503	SCREW
68	2504	SCREW
69	2508	SCREW
70	2505	SCREW
71	2506	SCREW
72	12610	SCREW
73	2532	SCREW
74	5201	SCREW
75	2509	SCREW
76	2512	SCREW
77	2003	AIR CYLINDER [CARBINE]
78	2045	BARREL .22 CARBINE
79	2507	HAMMERSPRING [SOFT]
80	5005	PLASTIC WASHER 2MM
81	2071	SIDEPLATE
82	2017	COCKING BOLT [BRASS]
83	2081	AIR TRANSFER PORT 2.0
84	2037	AIR TRANSFER PORT 1.5
85	11508	SCREW
86	2063	TRIGGER SPACER
87	BK51	O-RING .22 (5,5mm)

Spare parts available at:

spares.bagnallandkirkwood.co.uk

For spare parts not listed please contact us using the reference codes above